





	Cause	
Unable to pair	Switch not in pairing mode	Reset the Switch to factory mode
	Switch is away from the hub, or there are obstacles	Move Switch closer to the hub
	Switch is connected to another hub network	Reset the Switch to factory default

TROUBLESHOOTING

Product specifications, size, shape, and prices are subject to change without notice, and actual product appearance may differ from that depicted on the packaging.

TIS CONTROL LIMITED

RM 1502-p9 Easey Comm Bldg 253-261 Hennessy Rd Wanchai, Hong Kong

www.tiscontrol.com

Please read the user manual carefully before operation